

MAINTENANCE FOR EXTERIOR SHADES



To keep the Universal Motion Screen functioning properly, sidetracks should be kept clean and lubricated with a dry silicone spray (CRC Heavy Duty Silicone Spray or Super Tech Silicone Lubricant can be used and are found at most major automotive care retailers). This is often the solution to minor operational issues involving the raising and lowering of the shade.



The screen fabric is made of a vinyl coated polyester yarn designed for exterior use. White Microban is incorporated into the fabric, it does not prevent the visual accumulation of dirt and debris. Windex Pro Outdoor Products are recommended for cleaning. Simply attach the bottle to a garden hose and follow the directions provided on the cleaning product label.



Universal Screens Clear Vinyl Shades are a beautiful way to enclose a space and require regular cleaning to maintain clarity and shine. 303 Protectant is recommended in caring for vinyl shades. The cleaner is worked into the vinyl, leaving a hazy film. Simply polish the film off with a microfiber towel. This will enable the unit to operate smoothly and the vinyl to remain clear and polished.



- These shades are made to be used. Even when they are left down all of the time. Operate the shade or shades 1 to 2 times a week to make sure they are operating correctly before you might need to use them for something important.
- Spray vinyl inserts inside of side tracks 6-7 times a year or if you see the shade operate irregularly.